

# MOEN® 摩恩

## 沥水篮



文中图片仅供参考  
(款式因型号而异)

如需安装支持, 配件丢失等, 请联系MOEN。  
(中国) 400-630-8866  
www.moen.cn

©2023 Moen Incorporated

## 注意事项:


**MOEN® 摩恩** 厨卫产品以精湛的技术制造而成, 保证品质优良, 美观耐用。  
清洁产品时须小心, 避免对产品表面造成损害。  
请用清水或中性的清洁剂清洁产品表面, 然后以柔软的毛巾抹干;

切勿使用含化学成分或腐蚀性的清洁剂、粗糙的布料抹擦。


建议定期清洗产品, 以保证其外观光洁明亮。  
使用酸性清洁剂清洗附近物品时, 有可能损害产品表面, 请加倍小心。

## 安装与使用:


打开包装, 拿出沥水篮。




调整沥水篮两边的四个硅胶扣到合适的位置。



使用时, 调整沥水篮的可伸缩杆到适合的长度, 把沥水篮放置到水槽的上沿位置。



放置清洗后的餐具或食材解冻, 方便水分排走, 保持台面清洁干净。



在伸缩杆调整范围内使用沥水篮



伸缩杆调整到极限时请勿再拉伸



## 产品售后保修条款

摩恩产品是在高质量标准及生产工艺下制造的, 摩恩承诺为消费者购买的洁具产品提供有期限免费保修及终身维修服务。

厨房配件免费保修期为1年, 均自消费者购买日(以摩恩产品分销商开具的发票或收据上载明日期为准)起计。

免费保修范围为产品及产品配件由于材质及工艺原因而造成的故障或损坏。免费保修期内, 我们将无偿为您提供维修服务及更换发生故障的产品或产品配件。摩恩的售后服务责任仅限于对故障产品的修理, 而不延及您因产品故障而发生的其他损失, 法律另有规定的除外。

您需了解: 产品外观碰伤、刻划痕迹, 以及滥用及不正当保养所导致的故障或损坏, 均不属于免费保修范围。即使在免费保修期内, 属下列

- (1) - (5) 情况之一的, 需酌情收取修理费用:
1. 不能出示相符的保修卡和有效购买凭证情况的,
  2. 未按使用说明告知的使用方法和注意事项造成的故障,
  3. 自行拆卸、维修、改装所造成的故障和损坏,
  4. 由于不可抗力等外部原因引起的故障和损坏,
  5. 由于运输、搬卸、挤压等造成的损坏。

对于保修期外或不在保修范围内的产品, 如需维修, 摩恩将酌情收取上门费、人工费及材料费。本保修条款仅对原始消费者和酒店行业的购买者有效, 并不适用于本产品工业, 商业, 贸易和非酒店行业的使用。

如对本保修条款内容有任何疑问, 请拨打400 630 8866 咨询热线, 或向当地分销商咨询。

### MOEN® 摩恩

合格证  
Compliance Certification

产品名称 不锈钢沥水篮  
Product Name Drain Basket

检验员  
Inspector

生产日期  
Date of Production

富俊汇康科技(上海)有限公司  
中国(上海)自由贸易试验区新杨公路  
1300弄1号4幢207室  
邮编: 201413

Fortune Brands Innovations (Shanghai) Co., Ltd  
Room 207, Building 4, No.1, Lane 180, Xinyang Highway,  
China (Shanghai Pilot Free Trade Zone)

# MOEN 摩恩

## Drain Basket



The pictures in the text are for reference only  
(The style varies by model)

PLEASE CONTACT MOEN FIRST  
For Installation Help, Missing or Replacement Parts  
(China) 400-630-8866  
www.moen.cn

©2023 Moen Incorporated

### CAUTIONS:


**MOEN 摩恩** Kitchen products are made with superb technology to ensure high quality, beautiful and durable.  
Be careful when cleaning the product to avoid damage to the surface of the product. Please clean the surface of the product with water or neutral detergent, and then dry it with a soft towel;

Do not use chemical or corrosive cleaners or rough cloths.


It is recommended to clean the product regularly to ensure its appearance is bright and clean. When using acidic cleaners to clean nearby items, it may damage the surface of the product. Please be extra careful.

### Installation and Usage:


Open the package and take out the drain basket.




Adjust the four silicone buckles on either side of the drain basket to the correct position.



When you use, adjust the telescopic rod of the drain basket to an appropriate length and place the drain basket on the upper edge of the sink.




Place the washed tableware or the thawed food to drain the excess water and keep countertop clean.



Use a drain basket within the telescopic rod adjustment range.



Do not stretch the telescopic rod when it is adjusted to its limit.



### MOEN LIMITED WARRANTY

We offer limited warranty and lifetime maintenance for Moen products, which are all manufactured with high standards of workmanship.

The period of warranty shall start from the date of purchase of the product (according to the invoice or receipt issued by Moen distributors) and shall cover a period of the following: the warranty period for kitchen accessory is 1 year.

This warranty is your coverage against material and workmanship malfunction or defects in Moen products or components. During the warranty period, we offer free maintenance and changing of malfunctioned products or product components. Moen's after sales service liability is limited to the maintenance of faulty items and does not cover your other losses caused by product malfunction, except for otherwise stipulated by law. Cosmetic damages (scratches, dents, etc.) and malfunction or defects caused by abuse or improper maintenance is not covered by this warranty.

Although the warranty period remains valid, in case of the following conditions (1) - (5), the maintenance cost (material cost and labor cost) shall still be charged as the case may be:

1. Corresponding warranty card and valid invoice cannot be presented;
2. Faults were caused by the non-compliance with the instructions and precautions provided in the user's manual;

3. Damages and faults were caused by self-actuated dismantling, repair and refit;
4. Faults and damages were caused by external factors such as force majeure;
5. Damages were caused by transportation, unloading and extrusion, etc.

This warranty is valid for the original consumers only (including hotel use), and excludes industrial and commercial use of the product (except for hotel use). This card is only responsible for product maintenance rather than any other liabilities.

In the event that the product requires maintenance but exceeds the warranty period, or that the product is not covered by this warranty, labor cost and material cost shall be charged as the case may be.

Please call 400-630-8866 or contact local dealer for any question.

### MOEN 摩恩

合格证  
Compliance Certification

产品名称 沥水篮  
Product Name Drain Basket

检验员  
Inspector

生产日期  
Date of Production

富俊汇厨科技(上海)有限公司  
中国(上海)自由贸易试验区新杨公路  
1800弄1号4幢207室  
邮编: 201413

Fortune Brands Innovations (Shanghai) Co., Ltd.  
Room 207, Building 4, No.1 Lane 180, Xinyang Highway,  
China (Shanghai Pilot Free Trade Zone)